


# DIGITAL DRUM

## Instruction Manual




# Panel Controls

## Front Panel



- 1 Master volume knob**  
Control the volume of phone and line output.  
Turn it clockwise to increase the volume and anticlockwise to decrease it.
- 2 Pad select buttons and indicators**  
Select current pad. When you press them, the corresponding indicator lights up.
- 3 [tempo - / +] button**  
Change current tempo.
- 4 [click] button**  
Turn on or off the metronome.
- 5 [drum off] button and indicator**  
This button is used to turn on or turn off the drum voice of song.
- 6 [start/stop] button**  
Start or stop song playing.
- 7 [song / volume] button**  
Display the song number, accompaniment volume, drum volume, local/ external.
- 8 3-digit LED display**  
Display the parameters of current menu mode.
- 9 [voice / volume] button**  
Display the voice number, volume, pan and pitch value.
- 10 [kit] button**  
Display the drum kit number or reverb setting.
- 11 [utility] button**  
This button is used to enter or switch utility menu pages.
- 12 [+] and [-] buttons**  
These buttons are used to change the setting number of kit, voice, song and adjust the corresponding setting volume.
- 13 [save] button**  
Save current kit setting to a user kit.

## Rear Panel



### 14 Pad input jacks

Connect with pads, cymbals, hi-hat control, kick trigger.

### 15 Line output jacks (R, L/mono)

made up of right channel output and left channel output which is also used as mono line output.


### 16 Aux.in jack

Connect with external sound source.

### 17 Power supply jack (DC in 9V)

Connect an AC adaptor to this jack.

## Side Panel



### 18 Power switch

Turn the power on/off.

### 19 MIDI IN and OUT connector

Connect with external sound module.

### 20 USB Port

Connect to computer.

### 21 Phones jack

Connect a pair of stereo headphones to this jack. (Connect the headphones will not mute the output jacks.)

# Setup

## Caution!



To prevent electric shock and damage to the device, make sure the power is switched OFF on the drum and all related device before making any connection.

## Connect the pads and the pedal

Using the provided cables, connect each Trigger input jack on the rear panel of the module, and make sure each pad is connected to its corresponding Trigger input jack.


### Note:

1. The voice of hi-hat pad hitting is controlled by hi-hat pedal. Similar to a real drum kit, the hi-hat pad functions as an 'open hi-hat' when the pedal is stepped. When the pedal is released, it functions as a 'closed hi-hat'.
2. The valid striking area of a cymbal pad (ride, crash or hi-hat) is near the edge of the pad, which is different from other pads.




## Connect an audio equipment

1. When you want to listen to the voices with an amplifier, connect amplifiers with the Output L/MONO and R jacks on the rear panel. (For monaural playback, use the L/MONO jack; for stereo playback, connect both L/MONO and R jacks.)
2. The volume is adjusted with the VOLUME knob.



## Connect a CD player, etc.(Aux. In jack)


1. The audio output of a CD player, or other audio source, to connect with the AUX IN jack on the rear panel can be mixed with the sound of the drum. This function is convenient that let you play along with a favourite song.
2. The volume of the external signal is adjusted with the VOLUME knob.



## Connect headphones

An optional set of stereo headphones can be connected with the PHONES jack located on the side of the drum module.

- \* Adjust the volume to a comfortable level.




## Connect the power supply jack

Make sure the power is switched OFF and connect the power adaptor with the DC IN jack on the rear panel.

### Note:

1. To protect the speakers, amplifier and the drum module from damage, rotate the volume knob to the minimum volume level before switching the power ON.
2. Make sure the power is switched OFF when connecting drum module with external devices.



## MIDI and USB

MIDI stands for Musical Instrument Digital Interface, this is a world-wide standard communication interface that enables electronic musical instruments and computers (of all brands) to communicate with each other so that instructions and other data can pass between them. This exchange of information makes it possible to create a system of MIDI instruments and devices that offer far greater versatility and control than is available with isolated instruments. Whether you interface with computers, sequencers, expanders or other controllers, your musical horizons will be greatly enhanced.

### MIDI connection

**MIDI IN:** This terminal receives MIDI data from an external MIDI device.

**MIDI OUT:** This terminal transmits data from this instrument to other MIDI devices.

### USB connection

the USB connector allows you to connect the module directly to your computer. It can be connected without driver installation under the Windows XP & MAC OSX environment. The module will be recognized as 'USB Audio device' to receive and transmit MIDI messages through a single USB cable, USB is used only for MIDI messages(MIDI via USB).

Note: When the USB is connected to a computer, all MIDI messages will be received and transmitted via USB.

### LOCAL mode

From a MIDI point of view, the module is composed of two 'devices':

- \* A controller transmitting data: the pads and Hi-Hat control pedal (via an internal trigger to MIDI converter)
- \* A sound generator receiving MIDI data (the sound module).



In normal operation (Local ON, default mode), those two devices are connected together internally, allowing the pads to play the voices from the sound module without any external connection. When setting Local mode to Local OFF mode in the Utility menu, this internal link is disconnected. The sound module receives MIDI messages via MIDI input only, not from the pads anymore. However, the pad trigger data is still sent to the MIDI output, therefore looping externally the MIDI out of the module back to its MIDI In will enable the pads to play the voices from the sound module. Local OFF mode is intended to be used when both the MIDI input and output (or the USB port) of the module are connected to a MIDI sequencer with soft thru function (which loops the MIDI data received from the MIDI output back to the MIDI input). This prevents doubling or flanging effect when playing the pads (caused by the sound generator receiving the same MIDI data both directly from the pads and back through the sequencer).

### MIDI channels

MIDI channel 10: Primary percussion channel

MIDI channel 9: Secondary percussion channel


MIDI channel 1~8, 11~16: Melody voice channels




# Operation

## Switch the power ON

After confirming all connection have been completed, rotate the volume knob to the left ( minimum volume level) before switching the power on.




Set the power switch to "on" position to switch on the power. Display shows the kit's number and its indicator lights up.



## Set the main volume


While hitting a pad, gradually rotate the volume knob until a comfortable volume level is reached.



## Playing the pads


### Head shot

Hit only the head of pad.




### Rim shot

When playing the snare, you must strike both the head and rim of the pad.




### Cymbal Bow or Edge shots

Strike the bow of the pad to produce bow sounds ; And the edge sounds will be heard if you strike the edge of the pad.



### Cymbal choke

Choking the cymbal's edge with the hand immediately after hitting the cymbal makes sound stop.





## Play with a metronome

There are two types of sounds: Click ( Bell and click sounds) and Vocal Counting (one, two, three, four...)

1. Press the [ click ] button to start the metronome. The beat indicator is flashing and click sound begins to play.
2. Press the [ click ] button a second time, clicking voice will be switched to vocal counting.
3. Press the [ click ] button again to stop the metronome.


While the metronome is playing, the display shows the current time signature. There are five time signature types available (2/4, 3/4, 4/4, 5/4, 6/8), which can be selected by button [ + ] or [ - ].

Adjust the volume of the click sound  
Hold down the [ click ] button and press the [ + ] or [ - ] button, the display shows: "CXX" (XX= metronome volume, 00 to 16), press the press the [ + ] or [ - ] button again to adjust the volume.




## Select a drum kit

The unit comes with 20 (001-020) preset drum kits and 10 user kits (021-030). (Reference kit list: page 21)




1. Press [ kit ] button.  
The current kit number appears and the kit indicator lights.
2. Press [ + ] or [ - ] buttons to select drum kit number (001-050, looped) you want to use.



## Global reverb

1. In the kit number page, press the [ kit ] button to enter the global reverb mode, the LED shows the current reverb status ("roN" for reverb on of "roF" for reverb off).
2. Press the [ + ] or [ - ] buttons to turn or of off the global reverb effect.
3. Press the [ kit ] button again to return to the kit number page.






# Play a Song


## Select a song

This drum module has a total of 50 preset songs.

Note: The preset song setting is 001 after you slide on power.




1. Press [ song / volume ] button.  
The song indicator lights and the current song's number appears.
2. Press [ + ] or [ - ] buttons to select one of the song and listen to it.  
Song numbers 001 - 050 are preset songs.  
(Reference song list : page 21)



## Listen to the song

1. Press [ start/stop ] button and the pad's indicator will flash according to the song play., the song will start playback from the beginning.
2. The song will stop when it reaches the end.  
You can stop the song during playback by pressing the [ start/stop ] button.


**Note:** The pad's indicator can be lighted off by pressing [kick] button.



## Adjust the accompaniment volume

1. Press the [ song/volume ] button until "Axx" is displayed.  
(xx = accompaniment volume, 00 to 32)
2. Press [ + ] or [ - ] buttons to adjust the volume of song accompaniment.


\* It will be restored to default value on the next power on.



## Adjust the drum volume

1. Press the [ song/volume ] button until "dxx" is displayed.  
(xx = drums part volume, 00 to 32)
2. Press [ + ] or [ - ] buttons to adjust the song,s drum volume.


\* It will be restored to default value on the next power on.



# Create a User Drum Kit

## Set a drum voice

The unit comes with 307 high quality percussion sounds that you can assign to any of the drum pad, 3 cymbals, hi-hat control and bass drum. This way you can create your own drum kit that consists of the voice you want. (Reference voice list : page 20)  
The kit number 021-050 is use for saving your own drum kit.




1. Press [ voice ] button.  
The voice indicator lights and the display shows the voice number of this pad.
2. Press [ pad ] button or hit the pad you want to set. The pad indicator light and display shows the current voice number of lighting pad.
3. Press [ + ] or [ - ] buttons to select the voice number you want to assign.
4. Repeat step 2 and 3 for to set the voice for another pad or bass drum.

Note: When the snare pad is selected, press the [ rim ] button to select the snare rim ( or strike the rim of the snare pad.)  
When the cymbal pad (crash or ride) is selected, press the [ rim ] button to select the edge shot.

## Adjust the volume of the pad

This unit allows you to adjust the volume of every voices in the kit that let you control the individual level (volume) of the pads or bass drum.


1. Press the [ voice / volume ] button to select the volume level setting display shows : " L XX".  
(XX = level value, 00 to 32)  
The pad button indicator lights and display shows the current volume level of lighting pad.
2. Press the [ PAD ] button or kit the percussion pad you want to adjust.
3. Press the [ + ] or [ - ] buttons to increase or decrease the volume. While you are adjusting, hit the corresponding pad and listen carefully the sound level until reaching the level you want.
4. Repeat step 2 and 3 to adjust the volume of other pad voices.



## Adjust the pan of the pad

1. Press the [ voice ] button until the LED display shows : "PXX". (XX = Pan value, -8 to 8). The pad button indicator lights and display shows the current value of lighting pad.
2. Press the [ PAD ] button or hit the percussion pad you want to adjust.
3. Press the [ + ] or [ - ] buttons to adjust the level of the current pad.
4. Repeat step 2 and 3 to adjust the level of other pad.


Note: P-8 (left) -- 0 (center) -- P8 (right)



## Adjust the tuning of the pad

1. Press the [ voice ] button until the LED display shows : "tXX". (XX = Tuning value, -8 to 8). The pad button indicator lights and display shows the current value of lighting pad.
2. Press the [ PAD ] button or hit the percussion pad you want to adjust.
3. Press the [ + ] or [ - ] buttons to adjust the tuning of the current pad.
4. Repeat step 2 and 3 to adjust the level of other pad.


Note: P-8 (left) -- 0 (center) -- P8 (right)



## Set a user drum kit


Once completing to your own drum kit, you have to save them in the unit; otherwise your drum kit will be erased when you turn off the unit.

1. Press [ voice ] button.  
The kit number 021 appears and is flashing.
2. Press [ + ] or [ - ] buttons to set the kit number (021-050) for saving your drum kit.
3. Press [ save ] button again. The flashing kit number stops.
4. Repeat step 2 and 3 for to set the other user kits.



## Utility

Press [ utility ] button will enter utility menu and switch all utility menu pages in turn.




## Pad sensitivity

You can adjust the sensitivity(gain) of the inputs from pads.

1. Press the [ utility ] button until the display shows: "EXX", the pad sensitivity value is indicated. (XX=gain level value, 01 to 16)
2. Press [ pad ] button or hit the pad you want to set. The pad indicator light .
3. Press [ + ] or [ - ] buttons to adjust the sensitivity of pads. Range : 01-16  
Large values will produce a high sensitivity even if the pad is hit softly.  
Lower values will producing a low sensitivity even if the pad is hit forcefully.
4. Repeat step 2 and 3 for to set the voice for another pad or bass drum.

Note: If turn off the power without save, you will lose the changes you have just made.





## Rim sensitivity

Rim sensitivity(gain) of dual triggers (snare, crash and ride) can be adjusted to balance the head-rim velocities. Display shows: "rEX", (X=rim sensitivity level, 1 to 8).


1. Press the [ utility ] button until display shows: "rEX", the rim sensitivity level is indicated. (X=rim sensitivity level value, 1 to 8)
2. Press [ snare ], [ crash ] or [ ride ] button, then press [ rim ] button to adjust the rim sensitivity.
3. Press [ + ] or [ - ] buttons to adjust the rim sensitivity.
4. Repeat step 2 and 3 for to set the voice for another pad or bass drum.

**Note:** A bar will be shown instead of the sensitivity level if rim triggering is not supported by current selected pad.



## Crosstalk



1. Press the [ utility ] button until display shows: "oXX", the crosstalk value is indicated. (XX=crosstalk value, 01 to 16).
2. Press [ pad ] button or hit the pad you want to set. The pad indicator light .
3. Press [ + ] or [ - ] buttons to adjust the setting. This effect can be eliminated by setting this parameter to a higher value on the pad that is sounding inadvertently.
4. Repeat step 2 and 3 for to set the voice for another pad or bass drum.



## Velocity curve

This setting allows to control the relation between the velocity (Striking force) and the loudness (the dynamic curve).


1. Press the [ utility ] button until display shows: "CUX", the curve number is indicated. (X=curve number, 1 to 6).
2. Press [ pad ] button or hit the pad you want to set. The pad indicator light .
3. Press [ + ] or [ - ] buttons to adjust the setting.
4. Repeat step 2 and 3 for to set the voice for another pad or bass drum.



## Splash sensitivity



This setting controls the sensitivity of the foot splash.

1. Press the [ utility ] button until display shows: "FXX", the value number is indicated. (XX= value, -4 to 4).
2. Press [ + ] or [ - ] buttons to adjust the setting.



## Local

Local control on is the default function mode, display shows: "LoN". The internal link between pad triggers and sound generator will be broken when local control is turned off, display show: "LoF". In local control off mode, the sound module will receive MIDI messages via MIDI input only. But the functions of panel preview, clicking and song player are still available in this mode.





## MIDI output

One of the two different MIDI output formats can be select for the Digital Drum: the internal format (default setting) and the GM format. The internal format is used when the Digital Drum works as sound module (Digital Drum to Digital Drum); The GM format is used when some other sound module applied (the Digital Drum to other product), such as computer.

When the internal format is selected, the LED shows: "P-N", which means program change and then note-on/off (program change will always be transmitted for internal voice bank addressing). When the GM format is selected, the LED shows: "--N", which means only the 'note-on/off' will be transmitted (GM percussion note arrangement, program change not supported!).

**NOTE:** This setting will only affect the primary percussion channel (MIDI channel 10).



## Saving setting

Setting all the data (gain, rim sensitivity, crosstalk, velocity curve and splash sensitivity), you can save them into built-in-memory, press the [ save ] button to store all settings.

Note: If turn off the power without saving, you will lose the changes you have just made.

## Factory reset

This drum module will reset its to initial settings. Beware all data will be lost.

1. Turn the power off.
2. Turn on the power while holding the [ tempo - ] and [ tempo + ] Buttons

# Specifications

- Drum Pad:** 4 drum pads , 3 cymbal pads , 1 hi-hat control pedal , 1 kick trigger
- Voices:** 307 voices
- Drum kits:** 20 preset kits, 30 user kits
- Song:** 50 preset songs
- Controls:** MIDI IN / OUT, POWER SWITCH, USB, PHONES, START/STOP, SAVE, KIT, VOICE/VOLUME, SONG/VOLUME, DRUM OFF, CLICK, HI-HAT, CRASH, RIDE, HI-HAT CONTROL, SNARE, TOM 1, TOM 2, TOM3, KICK, VOLUME, + / -, TEMPO + / -
- Display:** LED display
- Connections:** Hi-hat control  
Hi-hat  
Crash  
Ride  
Snare  
Tom 1  
Tom 2  
Tom 3  
Kick  
Output (R & L/MONO)  
Aux in
- Power Supply:** AC adaptor (== 9V)

# Voice List

No. Name

**KICK**  
 001 Standard Kick 1  
 002 Standard Kick 2  
 003 Rock Kick 1  
 004 Rock Kick 2  
 005 Rock Kick 3  
 006 Room Kick 1  
 007 Room Kick 2  
 008 Jazz Kick 1  
 009 Jazz Kick 2  
 010 Jazz Kick 3  
 011 Bigband Kick  
 012 Funk Kick  
 013 Fusion Kick  
 014 Hiphop Kick 1  
 015 Hiphop Kick 2  
 016 Hiphop Kick 3  
 017 Hiphop Kick 4  
 018 1969s Kick  
 019 1971s Kick  
 020 1976s Kick  
 021 Pwrbd Kick  
 022 R&B Kick  
 023 House Kick 1  
 024 House Kick 2  
 025 House Kick 3  
 026 Drumbass Kick  
 027 808 Kick  
 028 909 Kick  
 029 Electronic Kick  
 030 Step Kick  
 031 Teckno Kick  
 032 Voic Kick  
 033 Lowfi Kick  
 034 Junkyard Kick  
 035 Disco Kick  
 036 Industry Kick  
 037 Noise Kick  
 038 Cartoon Kick

No. Name

**SNARE**  
 039 Star Snare 1  
 040 Star Snare Rim  
 041 Standard Snare 1  
 042 Standard Snare Rim  
 043 Standard Snare 2  
 044 Rock Snare 1  
 045 Rock Snare Stick  
 046 Rock Snare 2  
 047 Rock Snare 3  
 048 Room Snare 1  
 049 Room Snare Rim  
 050 Room Snare 2  
 051 Jazz Snare 1  
 052 Jazz Snare 1 Rim  
 053 Jazz Snare 2  
 054 Jazz Snare 2 Rim  
 055 Jazzlatin Snare  
 056 Bush Snare  
 057 Bigband Snare  
 058 Funk Snare 1  
 059 Funk Snare Stick  
 060 Funk Snare 2  
 061 Fusion Snare  
 062 Fusion Snare Stick  
 063 Pwrbd Snare  
 064 Hiphop Snare 1  
 065 Hiphop Snare 2  
 066 Ringo Snare  
 067 Ringo Snare Rim  
 068 Lowfi Snare  
 069 Lowfi Snare Stick  
 070 506 Snare  
 071 506 Snare Rim  
 072 506 Low Snare  
 073 506 Low Snare Rim  
 074 1969s Snare  
 075 1969s Snare Stick  
 076 1971s Snare  
 077 1971s Snare Stick  
 078 1976s Snare  
 079 1976s Snare Stick  
 080 R&B Snare  
 081 R&B Snare Stick  
 082 House Snare 1  
 083 House Snare Rim  
 084 House Snare 2  
 085 Step Snare  
 086 Step Snare Stick  
 087 Teckno Snare 1  
 088 Teckno Snare 2  
 089 Drumbass Snare  
 090 808 Snare  
 091 909 Snare  
 092 Electronic Snare  
 093 Junkyard Snare  
 094 Junkyard Snare Stick  
 095 Noise Snare  
 096 Industry Snare  
 097 Industry Snare Stick  
 098 Voice Snare  
 099 Voice Snare Stick  
 100 Cartoon Snare

No. Name

**TOM**  
 101 Standard Tom 1  
 102 Standard Tom 2  
 103 Standard Tom 3  
 104 Standard Tom 4  
 105 Standard Tom 5  
 106 Standard Tom 6  
 107 Rock Tom 1  
 108 Rock Tom 2  
 109 Rock Tom 3  
 110 Rock Tom 4  
 111 Rock Tom 5  
 112 Rock Tom 6  
 113 Room Tom 1  
 114 Room Tom 2  
 115 Room Tom 3  
 116 Room Tom 4  
 117 Room Tom 5  
 118 Room Tom 6  
 119 Jazz Tom 1  
 120 Jazz Tom 2  
 121 Jazz Tom 3  
 122 Jazz Tom 4  
 123 Jazz Tom 5  
 124 Jazz Tom 6  
 125 Brush Tom 1  
 126 Brush Tom 2  
 127 Brush Tom 3  
 128 Brush Tom 4  
 129 Brush Tom 5  
 130 Brush Tom 6  
 131 Funk Tom 1  
 132 Funk Tom 2  
 133 Funk Tom 3  
 134 Fusion Tom 1  
 135 Fusion Tom 2  
 136 Fusion Tom 3  
 137 1969s Tom 1  
 138 1969s Tom 2  
 139 1969s Tom 3  
 140 1971s Tom 1  
 141 1971s Tom 2  
 142 1971s Tom 3  
 143 1976s Tom 1  
 144 1976s Tom 2  
 145 1976s Tom 3  
 146 Old Tom 1  
 147 Old Tom 2  
 148 Old Tom 3  
 149 Hiphop Tom 1  
 150 Hiphop Tom 2  
 151 Hiphop Tom 3  
 152 Hiphop Tom 4  
 153 Hiphop Tom 5  
 154 Hiphop Tom 6  
 155 808 Tom 1  
 156 808 Tom 2  
 157 808 Tom 3  
 158 808 Tom 4  
 159 808 Tom 5  
 160 808 Tom 6  
 161 Electronic Tom 1  
 162 Electronic Tom 2  
 163 Electronic Tom 3  
 164 Electronic Tom 4  
 165 Electronic Tom 5  
 166 Electronic Tom 6  
 167 Step Tom 1  
 168 Step Tom 2  
 169 Step Tom 3  
 170 909 Tom 1  
 171 909 Tom 2  
 172 909 Tom 3

No. Name

173 Cartoon Tom 1  
 174 Cartoon Tom 2  
 175 Cartoon Tom 3  
 176 Junkyard Tom 1  
 177 Junkyard Tom 2  
 178 Junkyard Tom 3  
 179 Noise Tom 1  
 180 Noise Tom 2  
 181 Noise Tom 3  
 182 Voices Tom 1  
 183 Voices Tom 2  
 184 Voices Tom 3  
 185 Industry Tom 1  
 186 Industry Tom 2  
 187 Industry Tom 3  
 188 Timpani  
  
**RIDE**  
 189 Standard Ride20"  
 190 Standard Ride21"  
 191 Standard Ride21" Bell  
 192 Rock Ride21"  
 193 Rock Ride21" Bell  
 194 Bigband Ride  
 195 Bigband Ride Bell  
 196 Jazz Ride Bell  
 197 Step Ride  
 198 Step Ride Bell  
 199 1969s Ride  
 200 1969s Ride Bell  
 201 Pop Ride  
 202 Ska Ride  
 203 Orchestra Ride  
 204 Teckno Ride 1  
 205 Teckno Ride 2  
 206 Junkyard Ride 1  
 207 Junkyard Ride 2  
 208 Cartoon Ride  
 209 Voices Ride  
 210 Standard Ride21" Rim  
 211 Rock Ride21" Rim  
 212 1969s Ride Rim  
 213 Pop Ride Rim  
 214 Ska Ride Rim  
  
**CRASH**  
 215 Standard Crash 1  
 216 Standard Crash 2  
 217 Standard Crash 3  
 218 Standard Crash 1 Bell  
 219 Standard Crash 2 Bell  
 220 Standard China  
 221 Standard Splash8"  
 222 Standard Splash8" Bell  
 223 Rock Crash20"  
 224 Rock Splash8"  
 225 Jazz Splash10"  
 226 Jazz Splash10" Bell  
 227 Hiphop Crash  
 228 Hiphop Crash Bell  
 229 China Crash  
 230 China Carsh Bell  
 231 Orchestar Crash 1  
 232 Orchestar Crash 2  
 233 Orchestar Crash Bell  
 234 Mute Crash Bell  
 235 Drumbass Crash 1  
 236 Drumbass Crash 2  
 237 808 Crash 1  
 238 808 Carsh 2  
 239 909 Crash 1  
 240 909 Crash 2

No. Name

241 Junkyard Crash 1  
 242 Junkyard Crash 2  
 243 Noise Crash 1  
 244 Noise Crash 2  
 245 SFX Crash 1  
 246 SFX Crash 2  
 247 Industry Crash  
 248 Industry Crash Bell  
 249 Standard Crash 4  
 250 Standard Crash 5  
  
**HI-HAT**  
 251 Standard Hi-hat  
 252 Standard Hi-hat 2  
 253 Rock Hi-hat  
 254 Pop Hi-hat  
 255 Brush Hi-hat  
 256 1969s Hi-hat  
 257 Ska Hi-hat  
 258 House Hi-hat  
 259 808 Hi-hat  
 260 909 Hi-hat  
 261 Cartoon Hi-hat  
 262 Voices Hi-hat  
 263 Junkyard Hi-hat  
 264 Noise Hi-hat  
 265 Industry Hi-hat  
  
**PERCUSSION**  
 266 High Q  
 267 Slap  
 268 Scratch Push  
 269 DJ SFX  
 270 Sticks  
 271 Square Click  
 272 Metro Click  
 273 Metro Bell  
 274 Standard Clap  
 275 Tambourine  
 276 Standard Cow Bell  
 277 Mute Cow Bell  
 278 Rock Cow Bell  
 279 Vibraslap  
 280 Hi Bongo  
 281 Low Bongo  
 282 Mute Hi Conga  
 283 Open Hi Conga  
 284 Low Conga  
 285 High Timbale  
 286 Low Timbale  
 287 High Agogo  
 288 Low Agogo  
 289 Cabasa  
 290 Maracas  
 291 Short Whistle  
 292 Long Whistle  
 293 Short Guiro  
 294 Long Guiro  
 295 Claves  
 296 Hi Wood Block  
 297 Low Wood Block  
 298 Mute Cuica  
 299 Open Cuica  
 300 Mute Triangle  
 301 Open Triangle  
 302 Shaker  
 303 Jingle Bell  
 304 Belltree  
 305 Castanets  
 306 Mute Surdo  
 307 Open Surdo



## Drum Kit List

No.	Name	No.	Name	No.	Name
001	Fusion	008	House	015	Drumbass
002	Standard	009	Jazz	016	Funk
003	Room	010	Brush	017	Hiphop-3
004	Rock	011	1969songo	018	Huose-2
005	Hiphop	012	1971s	019	Vintage
006	Electronic	013	1976disco	020	Junkyard
007	Cartoon	014	909		
021	M-box	031	Hiphop	041	Drumbass
022	Step	032	Electronic	042	Funk
023	Industry	033	Cartoon	043	Hiphop-3
024	Lowfi	034	House	044	Huose-2
025	Metal	035	Jazz	045	Vintage
026	Pop-rock	036	Brush	046	Junkyard
027	Fusion	037	1969songo	047	M-box
028	Standard	038	1971s	048	Step
029	Room	039	1976disco	049	Industry
030	Rock	040	909	050	Lowfi

Note: Kit 1~20 are preset kits and kit 21~50 are user kits.

## Song List

No.	Name	No.	Name	No.	Name
001	Funk 1	018	Pop	035	Funk 2
002	Fusion 1	019	Rock 'n Roll 1	036	Acid Fusion
003	Latin Jazz	020	House	037	Folk Pop
004	Dance	021	Hip Hop	038	Latin
005	Big Band	022	6/8 Ballad	039	Ballad 2
006	Slow Fusion	023	Ballad 1	040	Disco
007	Samba	024	Boogie	041	8 Beat
008	Modern Jazz	025	Punk	042	Funk 3
009	Country	026	Rock 'n Roll 2	043	Slow Rock
010	Reggae	027	Metal	044	R&B 1
011	Salsa	028	16 Beat	045	R&B 2
012	Bluegrass	029	Rhumba	046	6/8 R&B
013	Mambo	030	Shuffle	047	Pop Rock
014	Beguine	031	Swing	048	Hard Rock
015	Drum 'n Bass	032	Blues 1	049	Pop Ballad
016	Jazz	033	Blues 2	050	New Age
017	Bossa	034	Fusion 2		

# Percussion Set List

		Standard	Room	Rock	Electronic	808	Jazz	Brush	Orchestra
27	D#1	High Q	<	<	<	<	<	<	Closed Hi-Hat 2
28	E 1	Slap	<	<	<	<	<	<	Pedal Hi-Hat
29	F 1	Scratch Push	<	<	<	<	<	<	Open Hi-Hat 2
30	F#1	Scratch Pull	<	<	<	<	<	<	Ride Cymbal 1
31	G 1	Sticks	<	<	<	<	<	<	<
32	G#1	Square Click	<	<	<	<	<	<	<
33	A 1	Metronome Click	<	<	<	<	<	<	<
34	A#1	Metronome Bell	<	<	<	<	<	<	<
35	B 1	Acoustic Bass Drum	<	<	<	<	Jazz Kick 2	Jazz Kick 2	Concert BD 2
36	C 2	Bass Drum 1	<	Rock Kick Drum	El Kick Drum	808 Kick Drum	Jazz Kick 1	Jazz Kick 1	Concert BD 1
37	C#2	Side Stick	<	<	<	<	<	<	<
38	D 2	Acoustic Snare	<	Rock Snare Drum	El Snare Drum	808 Snare Drum	808 Snare Drum	Brush Tap	Concert SD
39	D#2	Hand Clap	<	<	<	<	<	Brush Slap	Castanets
40	E 2	Electric Snare	<	<	<	<	<	Brush Swirl	Concert SD
41	F 2	Low Floor Tom	Room Low Tom 2	Rock Low Tom 2	El Low Tom 2	808 Low Tom 2	808 Low Tom 2	Brush Low Tom 2	Timpani F
42	F#2	Closed Hi-Hat	<	<	<	<	<	<	Timpani F#
43	G 2	High Floor Tom	Room Low Tom 1	Rock Low Tom 1	El Low Tom 1	808 Low Tom 1	808 Low Tom 1	Brush Low Tom 1	Timpani G
44	G#2	Pedal Hi-Hat	<	<	<	<	<	<	Timpani G#
45	A 2	Low Tom	Room Mid Tom 2	Rock Mid Tom 2	El Mid Tom 2	808 Mid Tom 2	808 Mid Tom 2	Brush Mid Tom 2	Timpani A
46	A#2	Open Hi-Hat	<	<	<	<	<	<	Timpani A#
47	B 2	Low-Mid Tom	Room Mid Tom 1	Rock Mid Tom 1	El Mid Tom 1	808 Mid Tom 1	808 Mid Tom 1	Brush Mid Tom 1	Timpani B
48	C 3	Hi-Mid Tom	Room Hi Tom 2	Rock Hi Tom 2	El Hi Tom 2	808 Hi Tom 2	808 Hi Tom 2	Brush Hi Tom 2	Timpani c
49	C#3	Crash Cymbal 1	<	<	<	<	<	<	Timpani c#
50	D 3	High Tom	Room Hi Tom 1	Rock Hi Tom 1	El Hi Tom 1	808Hi Tom 1	808Hi Tom 1	Brush Hi Tom 1	Timpani d
51	D#3	Ride Cymbal 1	<	<	<	<	<	<	Timpani d#
52	E 3	Chinese Cymbal	<	<	<	<	<	<	Timpani e
53	F 3	Ride Bell	<	<	<	<	<	<	Timpani f
54	F#3	Tambourine	<	<	<	<	<	<	<
55	G 3	Splash Cymbal	<	<	<	<	<	<	<
56	G#3	Cowbell	<	<	<	<	<	<	<
57	A 3	Crash Cymbal 2	<	<	<	<	<	<	Concert Cymbal 2
58	A#3	Vibraslap	<	<	<	<	<	<	<
59	B 3	Ride Cymbal 2	<	<	<	<	<	<	Concert Cymbal 1
60	C 4	Hi Bongo	<	<	<	<	<	<	<
61	C#4	Low Bongo	<	<	<	<	<	<	<
62	D 4	Mute Hi Conga	<	<	<	<	<	<	<
63	D#4	Open Hi Conga	<	<	<	<	<	<	<
64	E 4	Low Conga	<	<	<	<	<	<	<
65	F 4	High Timbale	<	<	<	<	<	<	<
66	F#4	Low Timbale	<	<	<	<	<	<	<
67	G 4	High Agogo	<	<	<	<	<	<	<
68	G#4	Low Agogo	<	<	<	<	<	<	<
69	A 4	Cabasa	<	<	<	<	<	<	<
70	A#4	Maracas	<	<	<	<	<	<	<
71	B 4	Short Whistle	<	<	<	<	<	<	<
72	C 5	Long Whistle	<	<	<	<	<	<	<
73	C#5	Short Guiro	<	<	<	<	<	<	<
74	D 5	Long Guiro	<	<	<	<	<	<	<
75	D#5	Claves	<	<	<	<	<	<	<
76	E 5	Hi Wood Block	<	<	<	<	<	<	<
77	F 5	Low Wood Block	<	<	<	<	<	<	<
78	F#5	Mute Cuica	<	<	<	<	<	<	<
79	G 5	Open Cuica	<	<	<	<	<	<	<
80	G#5	Mute Triangle	<	<	<	<	<	<	<
81	A 5	Open Triangle	<	<	<	<	<	<	<
82	A#5	Shaker	<	<	<	<	<	<	<
83	B 5	Jingle Bell	<	<	<	<	<	<	<
84	C 6	Belltire	<	<	<	<	<	<	<
85	C#6	Castanets	<	<	<	<	<	<	<
86	D 6	Mute Surdo	<	<	<	<	<	<	<
87	D#6	Open Surdo	<	<	<	<	<	<	<

# MIDI Implementation Chart

Function...	Transmitted	Recognized	Remarks
Basic Default	10 ch	1-16	
Channel Changed	X	X	
Mode Default	X	X	
Messages	X	X	
Altered	*****	*****	
Note Number: True voice	0-127 *****	0-127 0-127	
Velocity Note on	O 99H, V= 1-127	0-127	
Note off	O (99H. V= 0)	0-127	
After Key's	X	X	
Touch Channel's	X	X	
Pitch Bend	X	O	
Control 0	X	O	Bank Select
Change 1	X	O	Modulation
5	X	O	Portamento Time
6	X	O	Data Entry
7	X	O	Volume
10	X	O	Pan
11	X	O	Expression
64	X	O	Sustain Pedal
65	X	O	Portamento ON/OFF
66	X	O	Sostenuto Pedal
67	X	O	Soft Pedal
80	X	O	Reverb Program
81	X	O	Chorus Program
91	X	O	Reverb Level
93	X	O	Chorus Level
120	X	O	All Sound OFF
121	X	O	Reset All Controller
123	X	O	All Notes OFF
Program Change	O	O	
System Exclusive	X	O	
System : Song Position	X	X	
Common : Song Select	X	X	
: Tune	X	X	
System : Clock	O	X	START and STOP only
Real Time : Commands	O	X	
Aux : Local ON/OFF	X	X	
: All Notes OFF	X	X	
Messages : Active Sense	O	X	
: Reset	X	X	

O : YES

X : NO